



SPARE PARTS LIST  
ELECTRIC WATER HEATER GEYSER

Models


**AM 7022 I**

**AM 7022 U**

---

Edition 1 of 15 January 2002





MODELS	CODE	VALIDITY BY REGISTRATION	REF.
AM 7022 I	558310	2001440001	A
AM 7022 U	558311	2001440001	B

ER2002830046701001

<b>PART</b>	<b>CODE</b>	<b>DESCRIPTION</b>	<b>REF.</b>	<b>NOTE</b>
1	960142	Potent. Knob w/ F&R - HE (Blue)		
2	960072	Valve Knob w/ F&R (Blue)	A	
3	960110	Top Cover M2E Tap In	A	
3	960111	Top Cover M2E Tap Out	B	
4	960088	Accessories AR		
5	960019	Sliding Latch		
6	960089	Shower Head AR		
7	960016	Hose L = 120cm		
8	960020	Soap Tray		
9	960015	Filter 1/2"		
10	960011	Tank Fixing Clip		
11	960004	Outlet Fitting (Red)		
12	960003	Inlet Fitting (Blue)		
13	960002	Inlet Connection Pipe		
14	960096	Tap and Pressure Switch 2MS	A	
14	960097	Pressure Switch 2MS	B	
15	960021	Kit O-Ring and Fixing Fork		
16	960098	Heating Tank 7kW 220V		
17	960067	Thermostat 45A 85°C		
18	960102	Neon Lamp		
19	960101	Wiring Mechanical 7kW		
101	960000	External Tap + Gasket	B	

<b>NOTE</b>	<b>DESCRIPTION</b>		